

Reliable's

'74

**tea
sets**



445020



445030



445010



445040



445010
Two Place BARBIE® Tea Set (14 pcs.)

Consists of two cups, saucers, plates, one tea pot with lid, two sets of cutlery and two napkins with rings. Decorated plates and saucers. Individual set in a full colour display box. Packed 24 per carton. Weight 15.0 lbs.

445020
Four Place BARBIE® Tea Set (30 pcs.)


Consists of four cups, saucers, plates, one tea pot with lid, four sets of cutlery and four napkins with rings. Decorated plates and saucers. Individual set in a full colour display box. Packed 12 per carton. Weight 16.0 lbs.

445030
Four Place BARBIE® Tea Set (33 pcs.)

Consists of four cups, saucers, plates, goblets, one tea pot with lid, creamer, sugar bowl with lid and four sets of cutlery. Individual set in a full colour display box. Packed 12 per carton. Weight 20.0 lbs.

445040
Six Place BARBIE® Tea Set (53 pcs.)

Consists of six cups, saucers, plates, goblets, one tea pot with lid, creamer, sugar bowl with lid, six sets of cutlery and six napkins with rings. Individual set in a full colour display box. Packed 12 per carton. Weight 22.0 lbs.



446020



446030



446040

446020
Four Place BARBIE®
Breakfast Set
(30 pcs.)

Consists of four cups and saucers, one skillet, skillet cover, handle, sauce pan, sauce pan cover, cradle, coffee pot with lid, trivet and four sets of cutlery. Decorated saucers, skillet, sauce pan and coffee pot, complete with cookbook. Individual set in a full colour display box. Packed 12 per carton. Weight 24.0 lbs.

446030
Four Place BARBIE®
Bridal Set
(38 pcs.)

Consists of four cups, saucers, plates, two skillets and handles, one skillet cover, two sauce pans and cradles, one sauce pan lid, coffee pot with lid, trivet, four sets of cutlery and one cookbook. Decorated saucers, plates, skillets, sauce pans and coffee pot. Individual set in a full colour display box. Packed 12 per carton. Weight 30.0 lbs.

446040
Four Place BARBIE®
Royalty Set
(45 pcs.)

Consists of four cups, saucers, plates, two skillets with covers and handles, one tea pot with lid, one coffee pot with lid, two trivets, sauce pans, cradles, one roaster, roaster rack, platter, platter cradle, four sets of cutlery and one cookbook. Decorated saucers, plates, skillets, sauce pans, tea pot and coffee pot. Individual set in a full colour display box. Packed 6 per carton. Weight 20.0 lbs.



447020



447030



447040



447020
Four Place Corning Ware
Breakfast Set
(29 pcs.)

Consists of four cups and saucers, one skillet, skillet cover, handle, sauce pan, sauce pan cover, cradle, coffee pot with lid, trivet and four sets of cutlery. Decorated saucers, skillet, sauce pan and coffee pot. Individual set in a full colour display box. Packed 12 per carton. Weight 24.0 lbs.

447030
Four Place Corning Ware
Bridal Set
(37 pcs.)

Consists of four cups, saucers, plates, two skillets and handles, one skillet cover, two sauce pans and cradles, one sauce pan lid, coffee pot with lid, trivet and four sets of cutlery. Decorated saucers, plates, skillets, sauce pans and coffee pot. Individual set in a full colour display box. Packed 12 per carton. Weight 30.0 lbs.

447040
Four Place Corning Ware
Royalty Set
(44 pcs.)

Consists of four cups, saucers, plates, two skillets with covers and handles, one tea pot with lid, one coffee pot with lid, two trivets, sauce pans, cradles, one roaster, roaster rack, platter, platter cradle and four sets of cutlery. Decorated saucers, plates, skillets, sauce pans, tea pot and coffee pot. Individual set in a full colour display box. Packed 6 per carton. Weight 20.0 lbs.